Data sheet: MP6P.540.R1.ENG

www.aep.it

MP6Plus

LABORATORY PROFESSIONAL INDICATOR with 1, 2, 3 or 4 channels

Measurement of: WEIGHT, FORCE, PRESSURE, DISPLACEMENT, TEMPERATURE TORQUE, ANGLE and SPEED.



"THE EVOLUTION OF THE SPECIES": after more than 30 years of service in the various versions the new MP6Plue is born.

MP6*Plue* is a Professional Digital Laboratory Indicator with **1**, **2**, **3**, **or 4 inputs**, suitable for receiving signals from strain gauge sensors, transmitters with voltage or current output, PT100, potentiometers and ENCODERS.

Particularly suitable for both static and dynamic applications, for calibration and verification in metrology laboratories or industrial environments where it is necessary to make measurements of weight, force, pressure, torque, displacement and temperature in a <u>synchronized</u> manner.

To **FIT EVERY APPLICATION** the instrument can be configured and customized: the function keys F1, F2, F3 and F4 can be programmed for the function of interest such as: PEAK, HOLD, RELEASE, TX DATA DATALOG, DISCHARGE, ZOOM.

MP6*Plue* allows you to enable and disable each channel and using the **ZOOM** function it s possible to display only the channel of interest in full screen.

The instrument works with a resolution of ± 100.000 divisions and exceeds 0,005% accuracy due to an internal 24-bit Sigma-Delta AD converter and a measurement control system working at a frequency equal to the sampling frequency: this system provides a better suppression of interference caused by offset drift and connecting cables.

The sampling frequency (common to all channels) can be set from 2.5 samples per second up to 4800 samples per second therefore the instrument meets the needs of applications that require a considerable speed of response.

Each input channels can be supplied in 4 different configurations:

- Version with **input for strain gauge transducers** with standard resolution of ±100.000 div. suitable for working with load cells or force transducers with output ±2mV/V or ±3mV/V and 4 wires or 6 wires connection.
- Version with **voltage input** with standard resolution of ±100.000 div. suitable for working with pressure, torque transmitters, etc ... with output ± 10 V or ± 5 V.
- Version with **current input** with a standard resolution of ± 160.000 div. suitable for working with pressure, torque transmitters, etc ... with output 4-20mA or 0-20mA and 2- and 3-wires.
- Version with **temperature input** for PT100 eligible to work in the range from -50 °C to + 250 °C with 0.1 °C resolution and accuracy ± 1 °C.
- Version with **incremental ENCODER input** suitable for working with linear or rotary encoders. Also you can define whether to measure angle, displacement or speed.
- Version with **POTENTIOMETER input** suitable for working with linear transducers or displacement.

The instrument is equipped with a rear **USB** port to connect directly to a PC or Tablet.

As **OPTIONS**, the instrument can be equipped with:

- Additional input channels CH2, CH3 and CH4 with a synchronization system that allows to acquire at the same instant the measurement of all channels.
- One, two, three or four Analog Outputs programmable as voltage (±10 V, 0-5 V, 0-10 V, ±5 V) or current (4-20 mA, 0-20 mA, 0-24 mA) that can be associated to different channels or to the TOTAL (sum of two or more channels). The refresh rate of the analog signals is equal to the frequency of acquisition of the respective channels in input.
- A serial RS232C line to directly connect the device to a PC, PLC or a serial PRINTER.
- 4 programmable **DIGITAL INPUTS** 24Vdc.
- A serial **RS485** line with protocol MODBUS RTU normally used to connect multiple instruments in a same network to a PLC.
- WIRELESS transmission designed to transmit measurements to other devices by radio at a distance up to 100m.
- A powerful **DATALOGGER** with non-volatile memory, which allows to store data at the maximum acquisition speed, synchronize recordings with an internal clock-calendar and eventually export data to a file using an USB stick in .csv file format that can be transferred directly to Microsoft Excel.

Other features and functions of importance are:

- Graphical, large and high-resolution LCD display with backlit.
- Automatic UNIT CONVERSIONS in many specific units for each type of transducers.
- **MULTIMETER** function which displays the signal of the sensor directly in mV/V, V or mA.
- User selectable language: ITALIAN or ENGLISH.
- Function **ZERO** and **AUTOZERO** to reset automatically the measure if the measurement is below a set threshold.
- Function of HOLD, PEAK, programmable FILTER.
- Function of **DISCHARGE** in order to measure the amount of product discharged for example from a tank.
- Function **TOTAL** to perform the sum of the channels.
- Function **KEY LOCK** to protect the instrument settings by unauthorized persons.
- Function **CLOCK-CALENDAR** (Option) with date and time.
- 24 columns **PRINTER** (option) connected to the serial port through which it is possible to print the measuring points with the date and time and the data of the company that carried out the survey.

For each input channel, you can calibrate the signal coming from the sensor both in the **POSITIVE RANGE** and in the **NEGATIVE RANGE** (Example in tension and compression) through 3 different modes:

- Calibration with **Full Scale**: characterization through the programming of the transducer full scale and sensitivity in both the positive and negative range.
- Calibration for **POINTS**: linearity correction by programming 5 known points in both the positive and negative range.
- Known Weight: practice characterization (in the field) by imposing a known weight, pressure, torque to the sensor and calibrating the transducer output to this reference value.

To increase security the instrument has the ability to perform a **BACKUP** of all calibrations data so that you can recall them in case of accidental tampering.

MP6*Plus* may be accompanied by various applications and analysis software to perform calibrations for: PRESSURE FORCE and TORQUE measurements.

MP6*Plue* can be accompanied by the PC program **MP Supervisor** (Option) which allows easy connection between the instrumento and the pc over USB and allows you to display graphs or export data to Microsoft Excel.

The program also allows you to download the data log either stored on the internal memory or on a USB stick and easily compare the measurements.

Typical applications:

Calibration of reference machines: force, pressure and torque.

Calibration of materials testing machines.

Calibration of test benches and testing machine.

Calibration of transducers, pressure transmitters and pressure switches.

Calibration of load cells, force transducers and dynamometers.

Calibration of torque wrenches, snap or direct reading screwdrivers.

Audits between laboratories for the verification of measurement uncertainties.

Audit to perform metrological confirmations.

Audit for interlaboratory comparisons.

Quality control in production lines.


Quality Control in Calibration and Testing Laboratories.


Tests on materials such as springs, friction detection, breakout forces.

Tests on protective devices and safety.

Monitoring over time of mechanical quantities.

STANDARD CONFIGURATION





TECHNICAL DATA

STARDARD NUMBER OF CHANNELS	1 (CH1)
ACCURACY	≤± 0,005 %
LINEARITY ERROR	≤± 0,005 %
INTERNAL DIVISIONS	24 bit
CH1 INPUT: STRAIN GAUGE TRANSDUCERS	$\pm 2 \text{ mV/V}$ and $\pm 3 \text{ mV/V}$ (max $\pm 3,5 \text{ mV/V}$)
RESOLUTION	± 100.000 div
TRANSDUCERS POWER SUPPLY	
TYPE OF CONNECTION	5 Vdc switching (± 3 %)
TRANSDUCER RESISTANCE	4 or 6 wires
	from 100 Ω to 2000 Ω
CH1 INPUT: VOLTAGE AMPLIFIED TRANSDUCERS	± 10 V and ± 5 V
RESOLUTION	± 100.000 div
TRANSDUCERS POWER SUPPLY	20 Vdc (± 1 Vdc)
CH1 INPUT: CURRENT AMPLIFIED TRANSDUCERS	0-20 mA 4-20 mA
RESOLUTION	+200.000 div +160.000 div
TRANSDUCERS POWER SUPPLY	20 Vdc (± 1 Vdc)
CH1 INPUT: POTENTIOMETER	R min. 1 kΩ
POWER SUPPLY	5 Vdc
Unit Conversions for WEIGHT and FORCE	Kg, t, N, daN, kN, MN, lb, klb
Unit Conversions for PRESSURE	bar, mbar, psi, MPa, kPa, Pa, mH ₂ O inH ₂ O
	kg/cm ² , mmHg, cmHg, inHg, atm
Unit Conversions for TORQUE	N·m, N·mm, kN·m, kg·m, g·cm, kg·mm, ft·lbf, in·lbf
Unit Conversions for DISPLACEMENT	mm, m, foot, inch, cm, dm, μm
MULTIMETER FUNCTION	Direct Display in mV/V, Volt o mA
BACKLIT GRAPHIC DISPLAY	128 x 64 dots
CHARACTER SIZE	~ 13 mm
ADJUSTING DISPLAY CONTRAST	YES
TRANSDUCER CALIBRATION	Both in the POSITIVE and NEGATIVE range
TYPE OF DIGITAL CALIBRATION	Full Scale, Point Interpolation, Known Weight
FIELD LINEARITATION	On 1 5 measurement point
BACKUP AND RESTORE FUNCTION	Save and restore all configuration data
FUNCTION OF ZERO	100 % (on all the measurement range)
FUNCTION OF AUTOZERO	With TIME and THRESHOLD programming
FUNCTION OF PEAK	POSITIVE and NEGATIVE
FUNCTION OF DISCHARGE	YES
FUNCTION OF KEY BLOCK	Enabled through a Password
FUNCTION OF TOTAL (on all enabled channels)	YES
PROGRAMMABLE RESOLUTION	1 100
DIGITAL FILTER	0 5
PROGRAMMABLE DECIMAL POSITION POINT	0 5
PROGRAMMABLE CONVERSION RATE	from 2,5 to 4800 samples for second
INSTRUMENT LANGUAGE	ITALIAN and ENGLISH
FUNCTION KEYS programmable in configuration	F1-F2-F3-F4
Rear USB output, Connector type B	Max Cable Length 3,5 m
NOMINAL WORKING TEMPERATURE	0 +50 °C
MAX WORKING TEMPERATURE	0 +50 °C
STORAGE TEMPERATURE	-20 +70 °C
TEMPERATURE EFFECTS on the measurements	
a) on zero (10°C variation)	≤± 0,005 %
b) on full scale (10°C variation)	≤± 0,005 %
POWER SUPPLY	230 Vac ± 10 %
FREQUENCY	50/60 Hz
EXTERNAL PROTECTION FUSE	250 mA / 250 V
MAX. POWER REQUIRED	10 VA
CASE MATERIAL	Powder coated ALUMINIUM container
PROTECTION CLASS (EN 60529)	IP40
DEGREE OF ENVIRONMENTAL CONT.	11
WEIGHT	~ 0,8 kg
TENT	~ 0,0 kg

OPTIONS

INPUT CH2-CH3-CH4: STRAIN GAUGE TRANSDUCERS	$\pm 2 \text{ mV/V}$ and $\pm 3 \text{ mV/V}$ (max $\pm 3,5 \text{ mV/V}$)					
RESOLUTION	± 100.000					
TRANSDUCERS POWER SUPPLY	5 Vdc switching (± 3					
TYPE OF CONNECTION	4 or 6 v					
TRANSDUCER RESISTANCE	from 100 Ω to 2000 Ω					
INPUT CH2 – CH3 - CH4: VOLTAGE AMPLIFIED	±10 V e ±5 V					
TRANSDUCERS	± 100.000 div					
RESOLUTION	20 Vdc					
TRANSDUCERS POWER SUPPLY						
INPUT CH2 – CH3 - CH4: CURRENT AMPLIFIED	0-20 mA 4-20 mA					
TRANSDUCERS	+200.000 div +160.000 div					
RESOLUTION	20 Vdc					
TRANSDUCERS POWER SUPPLY						
INPUT CH2 – CH3 - CH4: POTENTIOMETER	R min. 1 kΩ					
POWER SUPPLY	5 Vdc					
INPUT CH2 – CH4: TEMPERATURE	PT100 2 wires (range -50 +250 °C)					
ACCURACY	±1°C					
RESOLUTION	±0,1 °C					
UNITS	°C, °F					
INPUT CH2 – CH4: incremental ENCODER	linear and rotary encoders					
TYPE OF INPUT	RS422 line driver alimentazione a 5Vdc (A+,A-,B+,B-)					
	5Vdc Open Collector (A,B)					
	TTL (A,B)					
Unit Conversions for DISPLACEMENT	m, dm, cm, mm, μm, foot, inch					
Unit Conversions for ANGLE Unit Conversions for SPEED	° (degrees) mm/min, m/min, ft/min, in/min, mm/s, m/s, ft/s, in/s,					
Offit Conversions for SPEED						
RS232C SERIAL output	rpm, Hz MAX cable Length 13 m					
RS485 MODBUS RTU (max 32 in multipoint)	MAX cable Length 13 m MAX cable Length 1000 m					
PRINTER output	24 columns (RS232C)					
	24 columns (N3232C)					
	The USB, RS232 and RS485 are INDEPENDENT so it is					
	possible to connect at the same time a PC, a PLC and a 24					
	columns serial printer.					
	On the report is it possible to print up to 3 header lines					
	with the company data. A measurement point will be					
USB	printed by pressing the key PRINT or using a remote digital					
	command.					
	You can print on both paper and adhesive labels.					
Analog Outputs	1, 2, 3 or 4 independent outputs					
Current Output	0-20 mA, 4-20 mA, 0-24 mA					
Voltage Output (max 20mA – RL min: 1kΩ)	0-5 V, 0-10 V, ± 10 V, ± 5 V					
DIGITAL INPUTS with programmable function	4					
WIRELESS transmission – only version with up to 2	433 MHz					
channels	100 m					
Max distance in free space						
-	I to keep them in internal memory even if you turn off the					
instrument.						
The logging can be done in AUTO mode or MANUAL mode.						
	ervals for a programmable time. The time interval between					
two measurements points can be varied from the maximum						
The MANUAL mode allows the operator to decide when to be given either via a button on the front panel or via a digita	p record the measurements on memory. The command can					
	wnloaded through the powerful software MP Supervisor or					
exported to external Flash Memory (USB stick) for charting,						
DATA LOGGER						
Max Storing Points	1 channel enabled: max. 130.000					
	2 channels enabled: max. 150.000					
	3 channels enabled: max. 32.000					
	4 channels enabled: max. 43.000					
	4 channels enabled +TOTAL: max. 26.000					
MAX PROGRAMMABLE TIME	100 days					
CLOCK - CALENDAR	Year, Month, Day, Hour, Minute, Seconds					
POWER SUPPLY	115 Vac or 24 Vdc					

COMPONENTS SUPPLIED










Power supply cable DB9 Male Connector for transducer

CD with Manual and USB Driver

COMPONENTS IN OPTION (purchased separately)





- I Fuse.
- Interruttore generale.
- USB output.
- Serial outputs, analog Outputs, digital inputs.
- **●** Input channel CH1 standard.
- Input channel CH2 option.
- Input channel CH3 option.
- Input channel CH4 option.

APPLICAZIONI SOFTWARE (to be purchased separately)




To complete the system of measurement **AEP transducers** has developed several software applications that interface directly to the instrument **MP6**²/₂ and support the user in the various functions of calibration, testing, analysis, data storage, transfer of measures on Microsoft Excel etc. ...

MPSupervisor is a software dedicated to **MP6**^{*p*}/_{*w*}. Through this software you can download the datalog and operate directly on **MP6**^{*p*}/_{*w*} to change parameters and create graphics test.

Quick Analyzer is a general-purpose acquisition software where **MP6**_{Plus} can be associated to other **AEP instruments**. For dedicated calibration applications 3 different software are available: **ForceKal, PressKal, TorqueKal.**

For more information download the manuals of the software on the site: www.aeptransducers.com www.aep.it

ForceKAL



Dedicated to the calibration of testing machines, test benches where force is generated.

PressKAL

Dedicated to the calibration of pressure gauges such as

- manometers
- pressure transducers
- pressure transmitters
- pressure switches

>	-		ple selection La		7 Devices Data	abase		
Pressure gauge Sample	Receiving d	ata and rem	ote comman	ds				
Type Calibration Certifica	ite			Resolu	ution	Measure U	nit	
LabDMM 54108P				1 2 mbar kPa psi				
Fondo Scala Unità Numero di Serie	Sam	ole Pressure						
500 bar 504198		DAG G	2	5	10	bar M	Pa	
Baudirate COM Decima		-49.9	<u> </u>	Zero	Por	.Peak	Neg.Peak	
		bar		2010	103			
		Dai		On		On	On	
				Off		Off	Off	
Open COM Close COM	A							
J								
	Calibration c	hart						
evices DataBase primo.dat	▼ Beference	Cycle 1	Cycle 1	Reading	Expanded	Reading	Exp.Uncert.	
Device in Calibration	pressure	Increasing	Diminishing	error	uncertainty	error	no correct	
Type Object	bar	pressure	pressure	bar	bar	%	bar	
PGE Digital pressure gau	ge 0.00	0.00 24.96	0.00	0.000	0.071	0.000	0.071	
Manufacturer Serial number	75.00	74.96	24.96	-0.040	0.071	-0.008	0.111	
	125.00	124.94	124.94	-0.040	0.071	-0.008	0.136	
AEP transducers 06001	200.00	199.92	199.92	-0.080	0.078	-0.016	0.158	
Full Scale Unit Resolu		249.92	249.92	-0.080	0.078	-0.016	0.158	
250 bar 0.1		÷						
Calibration Certificate CT00001								
		0.1.00						
Export in as xis	Excel file Beference pressure bar	Cycle 2-3 Increasing pressure	Calibration	n characteristi	cs	Calcu	ate Errors	
Export in		124.94	measurem	ent points m	easurement type		alculate	
as csv		124.92	5	- F	Pressure 💌		aiculate	
	ificate Repe	Repeatability						
DParis Micars New Cer								

TORQUEKAL


Dedicated to the calibration of torque wrench with direct reading or

snap.

						-	up.						
TorqueKal : Versi	ione 3.8												
e Intestazione certific	cati Archivio Strumenti Campioni Hel	o Archivio Dispo	isitivi										
		– Tabella di Tar	atura										
Сор	opia Applicata (Nm)	Coppia	Ciclo 1	Ciclo 2	Ciclo 3	Ciclo 4	Ciclo 5	Coppia	Media	Scostamento	Incertezza		a Misura (opremil
	-	Applicata		0000 2	0,0,0 0	0,0,0 4		Applicata	modela		Estesa	Barr	a Spaziatrice)
	10	Nm	Nm	Nm	Nm	Nm	Nm	Nm	Nm	%	20000	Camp	ione Utilizzato
	19	10.00	10.03	10.03	10.23	10.02	10.56	10.00	10.17	-1.710	4.618	DTB	
		30.00	29.99	31.30	30.50	30.45	31.21	30.00	30.69	-2.248	3.614	DTR	
rchivio Dispositivi T	TORSIOMETER 100NM	50.00	23.35	51.02	50.50	50.45	49.80	50.00	50.65	-2.240	1.846	DTR	
Dispositivo In Taratura			50.06	51.02	50.45	50.21	49.80		50.31	-0.612	1.846	Join	
Tipo	DK50	Caratteristiche	della Taratura —									Log	
	ChiaveDinamometrica	Decimali		-	Erro	ri							.og Corrente
Oggetto		N. Misure	C1 C	2				Calcola Err	ini (METER 100NM
Costruttore	Mabo			°								TURSIO	METER TOUNM
Numero di Serie	AD50-115674	Punto 3	50.00	lm		L'attrezz	o in taratura RI	ENTRA in tolleranza s	econdo la no	ma UNI EN ISO	6789		Edit File Log
Fondo Scala	50 Nm	Punto 2									and the day		
Unità di Misura	Nm	Punto 1	Punto 1 10.00 Nm Scostamento Ammissibile 25% 💌 Tipo di Misura Taratura in senso Orario 💌						Cr	ea Nuovo Log			
Risoluzione	.1 Nm	Lu I		T.			- 1				1.		Terr to a
Certificato di Taratura	CT02-228756	N. 10	Nome Dispositiv Torsiometer 100N	o Nume	rodiSerie)-115674 (Data 02/03/2013	0ra 16:16:27	Tipo di Misura Clockwise Calibra		Certificato N* CT02-228756		ento Ammissi 2.5%	Risultato OK
		11	Torsiometer 100h	lm AD50	-115674 (03/03/2013	17:09:35	Clockwise Calibra		CT02-228756		2.5%	OK
Configurazione RS232			Torsiometer 100M			04/03/2013	09:08:55	Clockwise Calibrat		CT02-228756		2.5%	OK
Canale Seriale COM	6 💌 Baud Rate 38400 💌		Torsiometer 100M Torsiometer 100M			05/03/2013 06/03/2013	08:33:34 10:56:22	Clockwise Calibra Clockwise Calibra		CT02-228756 CT02-228756		2.5% 2.5%	OK OK
			Torsiometer 100N			07/03/2013	10:06:22	Clockwise Calibra Clockwise Calibra		CT02-228756		2.5%	OK
			Torsiometer 100h			08/03/2013	11:22:25	Clockwise Calibra		CT02-228756		2.5%	OK
Esportazi	one dati in Excel (file .xls)		Torsiometer 100N			09/03/2013	17:17:56	Clockwise Calibral		CT02-228756		2.5%	OK
		18	Torsiometer 100M	m AD50	-115674	0/03/2013	13:09:29	Clockwise Calibral	tion	CT02-228756		2.5%	OK
Esportazio	one dati in Excel (file .csv)	19	Torsiometer 100N	lm AD50	0-115674	1/03/2013	16:33:45	Clockwise Calibrat	ion	CT02-228756		2.5%	OK
		20	Torsiometer 100N	m AD50	-115674	2/03/2013	16:12:11	Clockwise Calibral	tion	CT02-228756		2.5%	OK
			Torsiometer 100M	lm AD50	0.115674	3/03/2013	16:34:00	Clockwise Calibral	tion	CT02-228756		2.5%	OK
		22	Torsiometer 100N	lm AD50	-115674 1	4/03/2013	10:23:56	Clockwise Calibral	tion	CT02-228756		2.5%	OK
		23 24	Torsiometer 100M			15/03/2013	10:11:22	Clockwise Calibral	tion	CT02-228756		2.5%	OK
		24	Torsiometer 100M			6/03/2013	11:00:13	Clockwise Calibral	tion	CT02-228756		2.5%	OK.
	· · ·	25	Torsiometer 100N	Im AD50	-115674	7/03/2013	11:06:18	Clockwise Calibral	tion	CT02-228756		2.5%	OK
			Torsiometer 100M			18/03/2013	09:11:19	Clockwise Calibrat		CT02-228756		2.5%	OK
(manalinears)		27	Torsiometer 100M			9/03/2013	08:34:22	Clockwise Calibral	tion	CT02-228756		2.5%	OK
aradistansers	🍼 🖸 🟈	28	Torsiometer 100M			20/03/2013	09:21:44	Clockwise Calibrat		CT02-228756		2.5%	OK
	Setup		Torsiometer 100M			21/03/2013	11:11:56	Clockwise Calibral		CT02-228756		2.5%	OK
	setup		Torsiometer 100M			22/03/2013	15:33:04	Clockwise Calibra		CT02-228756		2.5%	OK
		<											
		Numero Prove	20	Prove In Tol	lorona n	30	Prove Fr	uori Tolleranza 0	. F	1 0.745		0.011	
		Numero Prove	30	Flove In 1 of	leranza	30	Flove FL	ion rollerariza U	c	ok 0.745	0	p 0.814	

QUICK ANALYZER


Dedicated to recording and graphical analysis of up to 16 different AEP transducers instruments to measure: force, weight, pressure, torque and displacement.



MP Supervisor

A dedicated program that allows an immediate interfacing through the USB port with the MP6Plus and allows you to view graphs, export data to Microsoft Excel directly from the PC and set all configuration parameters. The program also allows you to download a data log carried out using the internal memory or the USB Flash Memory and display the respective curves of acquisition.

1	MP Supervisor -	Version : 1.0	- 🗆 🗙					
CH 1 CH 2		MP Plus Configuration	Zero On					
Actual Setup Decimals	Quit		Peak+On Peak-On					
Add Total	Print Report	Peak + Zero Urr Hold Urr Acquisition Frequency 2.3 Field Cr Peak Off MP Supervisor Data Logger Manager MP Plus Report Header Data Lo						
Resolution 1 Calibration Parameters	Preview Report	Set Date and Time Indicator Connected : MP2Plus - Serial Number 0000 Ver: 1.2						
Graph Color Select	Select Printer	MP Supervisor Configuration C 1 Duadrant						
	- Total	C 2 Quadrants Graph MP Supervisor Report Configuration						
File Name XAxis Unit Acquisition Interval MAX V	Total Enabled	Data Folder C:\AEP transducers\WinMP2Plus\Data	Browse					
C s C min C hour Test Time D.D hour D.5 min	Graph FSY 2000000		DIOWSE					
FSX 30 s Load Curve Start Test	Graph Color Select							
CH1:Load (kg) FS		Test Starting Date: 14-01-2015 Test Starting Time: 16:51:51						
42749 CH1: 11000%9 CH2: 20000%9								
CH2:Load (kg)								
3575								
3373	$ \rightarrow $							
0			<u> </u>					
-FS								
0.0								



MOUNTING PANEL APPLICATION



Note: For mounting panel requires 2 special brackets.

PURCHASE CODES

	Inputs	Power	Analog Output	Serial Output	Functions	Accessories	Digital Inputs
MP6P	Х	XXX	XX	Х	Х	Х	X
	2	230	A1	S	D	Μ	Ν
	2 inputs	230 Vac	1 output	RS232, RS458 Modbus, Printer	Data logger Clock-Calendar	Handle	4 Digital Inputs
	3	115	A2	W	F		
	3 inputs	115Vac	2 outputs	Wireless	Datalogger		
	4 4 inputs	24 24Vdc	A3 3 outputs	Transmission	Clock-Calendar USB Flash Memory		
L			A4		Wentory		
			4 outputs				

Example: MP6P230 (MP6Plus power supply 230 Vac base version)

Example: MP6P224A2SM (MP6Plus 2 channels- power supply 24 Vdc + 2 Analog output + Serial output + handle) **Examples:** MP6P3115SF (MP6Plus 3 channels power supply 115 Vac + Serial output + USB Flash Memory)



<u>ALWAYS SPECIFY</u> in the purchase order how to configure the input channels. After the sale, the inputs <u>can not be changed</u> by the customer.

Example of channel configuration CH1: 2mV/V, 4-20mA, $\pm 10V$, POTENTIOMETER Example of channel configuration CH2: 2mV/V, 4-20mA, $\pm 10V$, POTENTIOMETER, PT100, ENCODER Example of channel configuration CH3: 2mV/V, 4-20mA, $\pm 10V$, POTENTIOMETER Example of channel configuration CH4: 2mV/V, 4-20mA, $\pm 10V$, POTENTIOMETER, PT100, ENCODER



In order to improve the technical performances of the product, the company reserves the right to make any change without notice.